



LASERJET PROFESSIONAL P1560 and P1600

SERIES PRINTER

For the complete PDF manual
please visit www.LaserPros.com.

Service Manual





HP LaserJet Professional P1560 and P1600 Series Printer

Service Manual

Copyright and License

© 2010 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CE663-90939

Edition 1, 4/2010

Trademark Credits

Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.

Conventions used in this guide

 **TIP:** Tips provide helpful hints or shortcuts.

 **NOTE:** Notes provide important information to explain a concept or to complete a task.

 **CAUTION:** Cautions indicate procedures that you should follow to avoid losing data or damaging the product.

 **WARNING!** Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

Table of contents

1 Theory of operation	1
Basic operation	2
Major product systems	2
Product block diagram	2
Sequence of operation	3
Normal sequence of operation	3
Formatter-control system	4
Sleep mode	4
Input/output	4
CPU	4
Memory	4
Firmware	5
Memory use	5
PJM overview	5
LEDM overview	5
ACL overview	5
Control panel	6
Engine-control system	7
Motors, fans, clutches, solenoids, switches, and sensors	8
DC controller operations	13
Fuser-control circuit	15
Fuser failure detection	16
Fuser temperature control	17
Fuser protective function	18
Pressure roller cleaning	18
Low-voltage power supply	19
Overcurrent/overvoltage protection	20
High-voltage power supply	21
Laser/scanner system	22
Laser failure detection	23
Image-formation system	24
Electrophotographic process	24
Image formation process	26
Latent-image formation stage	27

Primary charging	27
Laser beam exposure	27
Developing stage	28
Print cartridge	28
Transfer stage	29
Fusing stage	29
Cleaning stage	30
Pickup, feed, and delivery system	31
Photo sensors and switches	32
Main-input tray or priority input slot	34
Jam detection	34

2 Removal and replacement 35

Introduction	36
Removal and replacement strategy	36
Electrostatic discharge	37
Required tools	37
Before performing service	37
After performing service	38
Post-service test	38
Print-quality test	38
Parts removal order	39
Pickup roller	40
Separation pad	41
Transfer roller	42
Covers	43
Main-input tray	43
Output bin tray extension	44
Left cover, simplex product	45
Remove the left cover, simplex product	45
Left cover, duplex product	47
Remove the left cover, duplex product	47
Right cover, simplex product	50
Remove the right cover, simplex product	50
Right cover, duplex product	52
Remove the right cover, duplex product	52
Duplex door, duplex product	55
Duplex frame, duplex product	56
Remove the duplex frame	56
Cartridge door	57
Control panel	59
Front cover	61
Remove the front cover	61

Rear cover, simplex product	63
Remove the rear cover, simplex product	63
Face-down cover	65
Remove the face-down cover	65
Main assemblies	67
Formatter PCA	67
Laser/scanner assembly	68
Remove the laser/scanner assembly	68
Reinstall the laser/scanner assembly	71
Pickup assembly	72
Remove the pickup assembly	72
Reinstall the pickup assembly	78
Fuser	80
Remove the fuser	80
Reinstall the fuser	86
Main motor	87
Remove the main motor	87
Reinstall the main-motor drive belt	92
Pickup solenoid	93
Remove the pickup solenoid	93
Engine controller PCA	97
Remove the engine controller PCA	97
Reinstall the engine controller PCA	102
Duplex-reverse solenoid, duplex product	104
Remove the duplex-reverse solenoid	104
Main fan, duplex product	107
Remove the main fan	107
Reinstall the main fan	109
Duplex-connector PCA, duplex product	110
Remove the duplex-connector PCA	110
3 Solve problems	113
Solve problems checklist	114
Troubleshooting process	116
Determine the problem source	116
Power subsystem	117
Power-on checks	117
Tools for troubleshooting	118
Individual component diagnostics	118
Engine diagnostics	118
Engine-test button	118
Components tests	119
Drum rotation functional check	119

Half self-test functional check	119
Diagrams	120
Plug/jack locations	120
Location of connectors	121
Locations of major components	122
General timing charts	125
General circuit diagram	126
Internal print-quality test pages	127
Cleaning page	127
Configuration page	127
Print-quality troubleshooting tools	128
Repetitive defect ruler	128
Interpret control-panel light patterns	128
Clear jams	133
Common causes of jams	133
Jam locations	133
Clear jams from the input trays	134
Clear jams from the duplexer	136
Clear jams from the output areas	138
Clear jams from inside the product	139
Solve repeated jams	141
Change jam recovery	142
Solve paper-handling problems	143
Solve image-quality problems	144
Image defect table	144
Light print or faded	144
Toner specks	144
Dropouts	145
Vertical lines	145
Gray background	145
Toner smear	146
Loose toner	146
Vertical repetitive defects	146
Misformed characters	146
Page skew	147
Curl or wave	147
Wrinkles or creases	147
Toner scatter outline	148
Moisture	148
Change print density	149
Clean the product	150
Clean the pickup roller	150
Clean the paper path	151
Clean the print-cartridge area	153

Clean the exterior	154
Solve performance problems	155
Solve connectivity problems	156
Solve direct-connect problems	156
Solve network problems	156
Service mode functions	158
Product resets	158
Product updates	158
Firmware updates	158
4 Parts and diagrams	159
Order parts by authorized service providers	160
Order replacement parts	160
Related documentation and software	160
Supplies part numbers	160
Customer self repair parts	161
Service parts	161
Whole-unit replacement part numbers	161
How to use the parts lists and diagrams	162
Assembly locations	163
Base product (no optional trays or accessories)	163
Covers	164
Simplex model	164
Duplex model	166
Internal assemblies	168
Internal assemblies (1 of 3)	168
Internal assemblies (2 of 3)	170
Internal assemblies (3 of 3)	172
PCAs	174
Alphabetical parts list	176
Numerical parts list	179
Appendix A Service and support	183
Hewlett-Packard limited warranty statement	184
HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement	185
End User License Agreement	186
Customer self-repair warranty service	188
Customer support	188
Repack the product	189
Service information form	190
Appendix B Specifications	191
Physical specifications	192

Power consumption	192
Acoustic specifications	192
Environmental specifications	193
Appendix C Regulatory information	195
FCC regulations	196
Declaration of conformity	197
Certificate of Volatility	198
Safety statements	200
Laser safety	200
Canadian DOC regulations	200
VCCI statement (Japan)	200
Power cord instructions	200
Power cord statement (Japan)	200
EMC statement (Korea)	200
Laser statement for Finland	201
GS statement (Germany)	201
Substances Table (China)	202
Restriction on Hazardous Substances statement (Turkey)	202
Index	203

For the complete PDF manual
please visit www.LaserPros.com.